



## The body piece

## The collar



## The sleeves (cut 2)



## Notes

The seam allowance for raw edge is always 2 cm. That's going to give you some play for fitting a little as you sew the garment together. Wash and iron your fabric first to avoid shrinkage later.

The two important markings are the shoulder line (because it is your guide for attaching the sleeves) and your centre back line (because it is your guide for attaching the collar.)

The tools you will need are simple: Fabric, scissors, an iron, pins and either a sewing machine or needle and thread. It is entirely possible to sew this completely by hand, and it is probably easier to attach the collar that way.